

## **Panasonic GD95 WAP settings**

1. From the idle mode press the scroller in. Then choose **Browser->Browser Setting->Server Setting**. Select vacant profile and press the scroller in.
2. Select **Edit** press the scroller in.
3. A list of configuration parameters will be displayed. Fill the appropriate fields as shown below:  
Name - **Azercell**  
Home URL - **http://wap.azercell.com**  
Security - **Non Secure**  
Digital Dial # - **75767575111**  
Analog Dial # - *leave empty*  
Circuit Type - **Digital Only**  
PPP ID - **wapuser**  
PPP Password - **wap2000**  
Gateway IP - **062.217.128.038**
6. After all parameters have been entered, press **C** to return to the previous menu level. Select **Azercell** profile and press the scroller in. Choose **Set** and press the scroller in. Press NO button in order to return to the idle mode.
7. WAP settings entered. Now you can activate the browser by pressing the scroller in and choosing **Browser->Start Browser**.
8. To exit the Browser press NO button.

Thank you for using **WAPCELL !!**